


Simulation of optical photon propagation for generic scintillator-based detectors

Lecture 4 *Physics List*





Exercise – Example0

- Starting from the Blank project create your plastic scintillator tile of $10 \times 10 \times 1 \text{ cm}^3$ equipped with:
 - 4 SiPMs (type A) of 3mm size on two edges of your tile
 - 2 SiPMs (type B) of 6mm size on the center of two small faces
- Wrap your tile with a $300 \text{ }\mu\text{m}$ of Teflon
 - Suggestion: you need to «create the window» for your SiPMs (using multiple times G4Subtraction)

```
// World
G4double world_sizeX = 20*cm;
G4double world_sizeY = 20*cm;
G4double world_sizeZ = 20*cm;

G4double ScintillatorX = 10*cm;
G4double ScintillatorY = 10*cm;
G4double ScintillatorZ = 1*cm;
G4double SiPMThickness = 0.4*mm;
G4double WrappingThickness = 300*um;
G4double SiPMSize = 3*mm;
G4double SiPMSize2 = 6*mm;
```



- This part of the course provides an overview of Geant4:
 - its capabilities
 - how they can be used in an experimental simulation application (we will focus on the optical simulations)
- Geant4 is a complex and powerful toolkit
 - Impossible to teach (and learn) everything in few days and also our own expertise is not infinite
- This course would provide you with a global vision of Geant4 and a method for “how to use it”
 - Finding **your way** in the complexity of Geant4 is not easy
 - Use the Geant4 User Documentation and the “**BookForApplicationDevelopers**”

Geant4 web site: <http://cern.ch/geant4>

- What is necessary to built a complete simulation:

- Detector Construction:

- *Build your geometry, define your materials and eventually assign optical bulk and surface properties*

- Physics List:

- *“Activate” the physical processes that can occur during your simulation*

- Hit collection:

- *Define your “hit container”; i.e. which are the information that you want store during your simulation*

- Sensitive Detector:

- *Define your definition of hit; i.e. when you want to store the information*

- Action classes:

- *G4UserRunAction:*

- Define what happen at the begin and at the end of the **complete simulation**
 - Create an output file with its structure (Beginning)
 - Close the output file (end)

- *G4UserEventAction:*

- Define what happen at the begin and at the end of **each event**
 - Retrieve the information of each hit
 - Fill the output

- Composing a G4 application:


- General Classes:

- Initialization classes*


- G4VUserDetectorConstruction
- G4VUserPhysicsList

- Action classes*

- G4VUserPrimaryGenerationAction
 - G4UserRunAction
 - G4UserTrackingAction
 - G4UserStackingAction
 - G4UserSteppingAction



Classes Hierarchy



How to define a «Physics List»

- GEANT4 doesn't have any default particles or processes, but there are a set of "ready-for-use" physics lists released with G4.

- `PhysicsList()` class inherited from `G4VUserPhysicsList()`

- `ConstructParticle()`
 - Defines all necessary particles.
 - **G4ParticleDefinition**: name, mass, spin, PDG number, etc.
 - **G4DynamicParticle**: energy, momentum, polarization, etc.
- `ConstructProcess()`
 - Defines all necessary processes and assign them to proper particles.
- `SetCuts()`
 - Defines particles production threshold (in terms of range).

Particle	Process	G4Process
Photons	Gamma Conversion in e^{\pm}	<code>G4GammaConversion</code>
	Compton scattering	<code>G4ComptonScattering</code>
	Photoelectric effect	<code>G4PhotoElectricEffect</code>
	Rayleigh scattering	<code>G4RayleighScattering</code>
e^{\pm}	Ionisation	<code>G4eIonisation</code>
	Bremsstrahlung	<code>G4eBremsstrahlung</code>
	Multiple scattering	<code>G4eMultipleScattering</code>
e^{+}	Annihilation	<code>G4eplusAnnihilation</code>

A complete list and explanation of all the physical models implemented in Geant4 is available in the Application Developers Guide, Chapter 5

Your physics List (G4VUserPhysicsList)

- **ConstructParticle()**
 - Choose the particles you need in your simulation, define all of them here
- **ConstructProcess()**
 - For each particle, assign all the physics processes relevant to your simulation
- **SetCuts()**
 - Set the range cuts for the secondary production for processes

```
class MyPhysicsList : public G4VModularPhysicsList {  
public:  
    MyPhysicsList();           // define physics constructors  
    void ConstructParticle();   // optional  
    void ConstructProcess();    // optional  
    void SetCuts();             // optional  
}
```

Make your physics list

- **Reference to physics lists:** Take one/more pre-defined physics list
(*EASIEST used case*)
- **Physics constructors:** Combine pre-defined sets of particles and processes
(*INTERMEDIATE & for specific applications*)
- **Manually:** Specify all particles & process that may occur in the simulation
(*ADVANCED & for specific application*)

Particle categories

- Elementary particles which should be tracked in GEANT4 volumes

- All particles that can fly a finite length and interact with materials in detectors:

1. *stable particles*

- Stable means that the particle can not decay, or has a very small possibility to decay in detectors, e.g., gamma, electron, proton, and neutron.

2. *long life ($>10^{-14}$ sec) particles*

- Particles which may travel a finite length, e.g., muon, charged pions.

3. *short life particles that decay immediately in GEANT4 (e.g. π^0)*

4. *optical photon*

- Gamma and optical photon are distinguished in the simulation view, though both are the same particle (photons with different energies). **Optical photon is used for Cerenkov light and scintillation light.**

5. *geantino*

- Geantino is a virtual particles for simulation which do not interact with materials and undertake transportation processes only.

- Nuclei

- Any kinds of nucleus can be used in GEANT4, such as alpha (He-4), uranium-238 and excited states of carbon-14.

- Short-lived particles

- Particles with very short life time decay immediately and are never tracked in the detector geometry.
 - These particles are usually used only inside physics processes to implement some models of interactions.
 - quarks...

- **G4ParticleDefinition:**

- Define and see properties of particles:
 - *PDG encoding*
 - *mass and width*
 - *electric charge*
 - *spin, isospin and parity*
 - *magnetic moment*
 - *quark contents*
 - *life time and decay modes*

- **Particle list:**

- This list is generated automatically by using GEANT4 functionality, so listed values are same as those in your GEANT4 application.
- **Categories**
 - *gluon / quarks*
 - *leptons*
 - *mesons*
 - *baryons*
 - *ions*
 - *others*


G4ParticleDefinition() get methods

G4String GetParticleName()	particle name
G4double GetPDGMass()	mass
G4double GetPDGWidth()	decay width
G4double GetPDGCharge()	electric charge
G4double GetPDGSpin()	spin
G4double GetPDGMagneticMoment()	magnetic moment (0: not defined or no magnetic moment)
G4int GetPDGiParity()	parity (0: not defined)
G4int GetPDGiConjugation()	charge conjugation (0: not defined)
G4double GetPDGIsoSpin()	iso-spin
G4double GetPDGIsoSpin3()	3 rd -component of iso-spin
G4int GetPDGiGParity()	G-parity (0: not defined)
G4String GetParticleType()	particle type
G4String GetParticleSubType()	particle sub-type
G4int GetLeptonNumber()	lepton number
G4int GetBaryonNumber()	baryon number
G4int GetPDGEncoding()	particle encoding number by PDG
G4int GetAntiPDGEncoding()	encoding for anti-particle of this particle

G4DynamicParticle() get methods

G4double theDynamicalMass	dynamical mass
G4ThreeVector theMomentumDirection	normalized momentum vector
G4ParticleDefinition* theParticleDefinition	definition of particle
G4double theDynamicalSpin	dynamical spin (i.e. total angular momentum as a ion/atom)
G4ThreeVector thePolarization	polarization vector
G4double theMagneticMoment	dynamical magnetic moment (i.e. total magnetic moment as a ion/atom)
G4double theKineticEnergy	kinetic energy
G4double theProperTime	proper time
G4double theDynamicalCharge	dynamical electric charge (i.e. total electric charge as a ion/atom)
G4ElectronOccupancy* theElectronOccupancy	electron orbits for ions

- All GEANT4 processes are treated generically.
- A process does two things:
 - *decides when and where an interaction will occur*
 - **method: `GetPhysicalInteractionLength()`**
 - this requires a cross section or a decay lifetime
 - for the transportation process, the distance to the nearest object along the track is required
 - *generates the final state of the interaction (changes momentum, generates secondaries, etc.)*
 - **method: `DoIt()`**
 - this requires a model of the physics
 - Physics processes describe HOW particles interact with material
 - G4 apply defined physics on the defined particles using three kinds of actions:
 - ***AtRest actions:***
 - Decay, e+ annihilations,...
 - ***AlongStep actions:***
 - To describe continuous actions, occurring along the path of the particle, like ionisation.
 - ***PostStep actions:***
 - For describing point-like actions, like decay in flight, hadronic interactions,...




G4Track concept

- G4Track keeps ‘current’ information of the particle
 - *energy, momentum, position, time* (‘dynamic’ information)
 - *mass, charge* (‘static’ information)
- GEANT4 tracks particles step by step inside the defined geometry.
 - *Only processes can change information of G4Track and add secondary tracks*
 - *G4Track is updated after each invocation of a PostStepDoIt.*


G4Step concept

- A G4Step can be seen as a “segment” delimited by two points
 - *It contains “delta” information (energy loss along the step, time-offlight, etc)*



- There are three kinds of basic processes:

- well-located in space → PostStep
- distributed in space → AlongStep
- well-located in time → AtRest



- A generic process

- G4VProcess is a base class of all processes and it has 3 kinds of DoIt methods and a GetPhysicalInteraction method in order to describe generically the interactions.
- “Shortcut” processes are defined which invoke only one “physics” (DoIt action)
 - Discrete process (has only PostStep physics)
 - Continuous process (has only AlongStep physics)
 - AtRest process (has only AtRest physics)


- In the generic case six methods must be implemented, one GetPhysicalInteractionLength() and one DoIt() for each type of simple process

- After each DoIt, ParticleChange updates PostStepPoint based on proposed changes.
 - eg: decay = AtRest + PostStep

Handling multiple processes

1. A particle is shot and “transported”.
2. All processes associated to the particle propose a **geometrical** step length (depends on process cross-section).
3. The process proposing the **shortest** step “wins” and the particle is moved to destination.
4. All processes **along the step** are executed (e.g. ionization)
5. Post step phase of the process that limited the step is executed. New tracks are “pushed” to the stack
6. If $E_{\text{kin}}=0$ all **at rest processes** are executed:
 if particle is stable the track is **killed**
 ... else...

New step starts and sequences repeats,...



Retrieve your information (Stepping Action example)

- Track and Step information may be accessed by invoking various Get methods provided in the G4Track and G4Step class

Example: Processing a single step (G4Step *aStep) and verify if an optical photon is absorbed (detected)

```
G4Track *aTrack = aStep->GetTrack();
const G4ParticleDefinition* aDef = aTrack->GetParticleDefinition();
G4String particleName = aDef->GetParticleName();
if(particleName=="opticalphoton"){
    G4String procName= aStep->GetPostStepPoint()->GetProcessDefinedStep()->GetProcessName();
    if(G4StrUtil::contains(procName,"Absorption")){
        G4String absVolume = aStep->GetPostStepPoint()->GetPhysicalVolume()->GetName();
        G4cout<<"[INFO]: A Photon was absorbed in "<<absVolume<<G4endl;
    }
}
```


- In Geant4 there are no tracking cuts
 - particles are tracked down to a zero range/kinetic energy
 - **Only production cuts exist** i.e. *cuts allowing a particle to be born or not*
- Why are production cuts needed ?
 - Some processes could involve divergences
 - this leads to an infinity [huge number] of smaller and smaller energy
 - e.g. photons/electrons for Bremsstrahlung, δ -ray production...
 - production cuts limit this production to particles above the threshold
 - the remaining, “divergent part” is treated as a continuous effect (i.e. AlongStep action)
- A range cut allows to easily define such visibility:


“I want to produce particles able to travel at least 1 mm”

No secondary particles will be produced in the detector inside this distance
- The same energy cut leads to very different ranges
 - for the same particle type, depending on the material
 - for the same material, depending on particle type
- The user specifies a range cut in the PhysicsList
 - this range cut is converted into energy cuts
 - each particle (G4ParticleWithCut) converts the range cut into an energy cut, for each material
- Processes then compute the cross-sections *based on the energy cut*

Range vs. energy production cuts

- You can set a “range” production threshold
 - This threshold is a **distance**, not **an energy**.
 - Particles unable to travel at least the range cut are not produced
 - Energy is conserved
 - Production threshold is internally concerted to the **energy thresholds** depending on particle type and material:
 - Effective energy threshold is different in each material
- You can also create sub-regions in your detector with their own cuts
 - In the geometry an instance of G4Region must be created which corresponds to the volume where the cuts are to be changed

500 MeV p in
LAr-Pb sampling
calorimeter




Threshold in range: 1.5 mm



455 keV electron energy in liquid Ar
2 MeV electron energy in Pb

the best compromise




Pre-defined Physics Lists

- Pre-packaged physics lists:
 - Geant4-toolkit provides pre-packaged physics lists *according to some reference use cases*
 - These are “ready-to-use”, complete physics lists provided by the toolkit and constructed by the **expert developers**
 - each pre-packaged physics list includes different combinations of EM and hadronic physics
 - The list of these pre-packaged physics lists can be found in
`$G4DIR/src/geant4/source/physics_lists/lists/include`
- A guide is available at:

<https://geant4-userdoc.web.cern.ch/UsersGuides/PhysicsListGuide/html/index.html>

FTFP_BERT.hh	FTF_BIC.hh	G4PhysListStamper.hh	QBBC_ABLA.hh	QGSP_FTFP_BERT.hh
FTFP_BERT_ATL.hh	G4GenericPhysicsList.hh	G4RegisterPhysicsLists.icc	QGSP_BERT.hh	QGSP_INCLXX.hh
FTFP_BERT_HP.hh	G4GenericPhysicsList.icc	INCLXXPhysicsListHelper.hh	QGSP_BERT_HP.hh	QGSP_INCLXX_HP.hh
FTFP_BERT_TRV.hh	G4PhysListFactory.hh	INCLXXPhysicsListHelper.icc	QGSP_BIC.hh	QGS_BIC.hh
FTFP_INCLXX.hh	G4PhysListFactoryAlt.hh	LBE.hh	QGSP_BIC_AllHP.hh	Shielding.hh
FTFP_INCLXX_HP.hh	G4PhysListFactoryMessenger.hh	NuBeam.hh	QGSP_BIC_HP.hh	ShieldingLEND.hh
FTFQGSP_BERT.hh	G4PhysListRegistry.hh	QBBC.hh	QGSP_BIC_HPT.hh	



Physics Lists

- “**QGS**” Quark gluon string model ($>\sim 20$ GeV)
- “**FTF**” Fritiof Model ($>\sim 10$ GeV)
- “**LHEP**” Low and High energy parameterization model
- “**BIC**” Binary Cascade Model ($<\sim 10$ GeV)
- “**BERT**” Bertini Cascade Model ($<\sim 10$ GeV)
- “**HP**” High Precision Neutron Model ($<\sim 20$ MeV)
- “**PRECO**” Pre compound Model ($<\sim 150$ MeV)
- “**EMV(X)**” Variation of Standard EM package

- “Production physics lists”:
 - these physics lists are used by large user groups like ATLAS, CMS, etc.
 - they are well-maintained and tested physics lists they are changed, updated less frequently
 - very stable physics lists they are extensively validated by the developers and the user communities FTFP_BERT, QGSP_BERT, QGSP_FTFP_BERT_EMV, FTFP_BERT_HP, QGSP_BIC_EMV, QGSP_BIC_HP, QBBC, Shielding
- FTFP_BERT: Recommended by Geant4 developers for HEP applications
 - Add your “standard” EM physics constructors:
 - G4EmStandardPhysics* - standard, for “higher energy physics”
 - G4EmStandardPhysics_option1* - for HEP, fast but not precise settings
 - G4EmStandardPhysics_option2* - for HEP, experimental
 - G4EmStandardPhysics_option3* - for medical and space science applications
 - G4EmStandardPhysics_option4* - most accurate EM models and settings**
 - Pre-packaged physics lists are provided as a “best guess” of the physics needed in some given use cases
 - *when a user decide to use them, the user is responsible for “validating” the physics for that given application and adding (or removing) the appropriate physics*

Reference physics lists: myPhysicsList Class

• Pre-defined physics lists

- Already containing a complete set of particle & processes (that work together)
- Targeted at specific area of interest
- Constructed as modular physics lists built on top of physics constructor
- Customizable (adding/calling appropriate methods **before initialization**)

```
PhysicsList::PhysicsList()
:G4VUserPhysicsList()
{
    //Same Physics of FTFP_BERT
    //EM Physics
    emPhysicsList = new G4EmStandardPhysics();
    //Synchrotron Radiation & GN Physics
    emExtraPhysics = new G4EmExtraPhysics();
    //Decays
    DecayPhysics = new G4DecayPhysics();
    // Hadron Elastic scattering
    HadronElastic = new G4HadronElasticPhysics();
    // Hadron Physics
    HadronPhysics = new G4HadronPhysicsFTFP_BERT();
    // Stopping Physics
    StoppingPhysics = new G4StoppingPhysics();
    // Ion Physics
    IonPhysics = new G4IonPhysics();
    //Neutron Physics
    NeutronPhysics = new G4NeutronTrackingCut();
}
```

See myPhysicsList example to create your complete PhysicsList class and add it to your simulation

[myPhysicsList.hh](#)
[myPhysicsList.cc](#)

Exercise – Example1A

- Add your physics list to your simulation (Example0) and activate the optical processes
 - Try to run a simulation

Reference physics lists

-- In your main() --

```
G4RunManager* runManager = new G4RunManager;

...

// Physics list
G4VModularPhysicsList* physicsList = new FTFP_BERT;
physicsList->ReplacePhysics(new G4EmStandardPhysics_option4());
auto opticalPhysics = new G4OpticalPhysics();
physicsList->RegisterPhysics(opticalPhysics);
runManager->SetUserInitialization(physicsList);
```

-- In your macro file --

```
/process/optical/processActivation Cerenkov true
/process/optical/processActivation OpAbsorption true
/process/optical/processActivation OpBoundary true
/process/optical/processActivation Scintillation true

/process/optical/scintillation/setByParticleType false
/process/optical/scintillation/setFiniteRiseTime false
/process/optical/scintillation/setTrackSecondariesFirst false

/process/optical/cerenkov/setMaxPhotons 50

/run/initialize
```

Reference

\$G4INSTALL_DIR/share/Geant4/examples/extended/optical/OpNovice2/

**Remember to initialize the kernel
after adding all the optical
properties**