


# Simulation of optical photon propagation for generic scintillator-based detectors

## *Lecture 6*

### *Sensitive Detector and Output file*



Davide Serini  
[davide.serini@ba.infn.it](mailto:davide.serini@ba.infn.it)

- **General G4 introduction**
  - **How to run the example B1**
    - *Build and run the code*
    - *Run a simple simulation using the User Interface*
    - *Run a simple simulation using a macro*
- **Make your own project**
  - **Build your project:**
    - *Main*
    - *Geometry*
    - *Physics list*
    - *Write a macro*
  - **Build your simulation: data management tools:**
    - *Sensitive Detector*
    - *Hit collection*
    - *Run Action*
    - *Event Action*
  - **Make your simulation (final exercise)**

# Simulation data storage: the «Sensitive Detector» concept

- **The STEP concept**

A G4Step can be seen as a “**segment**” delimited by two points. It contains “delta” information (energy loss along the step, time-offlight, etc)



- **The HIT concept**

- A G4hit is a **snapshot of the physical interaction** of a track **in the sensitive region** of a detector.

- In a “hit” you can store information associated with G4Step objects.

- *the position and time of the step,*
- *the momentum and energy of the track,*
- *the energy deposition of the step,*
- *geometrical information,*

- **The G4HitCollection:**

- During the processing of a given event, represented by a G4Event object, **many objects of the hit class will be produced, collected and associated with the event.** Therefore, for each concrete hit class you must also prepare a concrete class derived from G4VHitsCollection, an abstract class which represents a vector collection of user defined hit.

- **The Sensitive Detector concept**

- G4VSensitiveDetector is an abstract base class which **represents a detector.** The principal mandate of a sensitive detector **is the construction of hit** objects using information from steps along a particle track.
- The ProcessHits() method of G4VSensitiveDetector performs this task using G4Step objects as input.

- **Sensitive Detector vs. Stepping Action:**

- In the Sensitive Detector the hit is built during the processment of an event
- In the Stepping Action the user process all the steps

- **Run Action:**

- **Actions to do at the beginning and at the end of each «run» of simulations**
  - *Creation of the input file and definition of the trees (begin of Run)*
  - *Storage of the trees in the output file (end of Run)*
  - ...

- **Process Hit**

- **Actions to do during the simulation in order to create and manage the hits in the sensitive detector**
  - *Ouw definition of hit*
  - *Step processing*
  - *Hit storage*

- **Event Action**

- **Actions to do at the beginning and at the end of each «event»:**
  - *Creation of a collection of Hits associates to that event (begin of Event)*
  - *Reading and storing the hits in the tree*

## Exercise 2.A

---

- **Exercise 2.A:**

- **Promote your detectors as «sensitive»**
- **Create your Hit collection class and your definition of hit trying to retrieve the following informations:**
  - *The total energy deposited by all particles produced in each event («total dose»)*
  - *The track length of one kind of particle (e.g. electrons) eventually produced inside your detector*
  - *The amount of detected photon by your sensor (SiPM)*
- **Processing the hit and:**
  - *Print on screen (for debug mode) if and where those electrons are produced*
  - *Store the hit at the EndOfEvent*
  - *Clear the Sensitive detector status at the EndOfEvent*

**For this exercise we need to act on the `DetectorConstruction.cc` `OneHit.cc` `OneHit.hh` `SensitiveDetector.cc` `SensitiveDetector.hh`**

# Detector Construction

```
//Sensitive Detector
G4SDManager *SD_manager = G4SDManager::GetSDMpointer();
G4String SDModuleName = "/SensitiveDetector";
if(SD_manager->FindSensitiveDetector(SDModuleName,true))
    delete(SD_manager->FindSensitiveDetector(SDModuleName,true));
SensitiveDetector *sensitiveModule = new SensitiveDetector(SDModuleName,"HitCollection"
SD_manager->AddNewDetector(sensitiveModule);

logicScint->SetSensitiveDetector(sensitiveModule);
logicWrapping->SetSensitiveDetector(sensitiveModule);
logicSiPM->SetSensitiveDetector(sensitiveModule);
```

Add here ALL your hit collections

***Promote your logic volume to Sensitive***

# OneHit class

## OneHit.hh

```
#ifndef OneHit_h
#define OneHit_h 1

//Include Native G4 Classes
#include "G4VHit.hh"
#include "G4Allocator.hh"
#include "G4THitsCollection.hh"
#include "G4ThreeVector.hh"
#include "G4UnitsTable.hh"
#include "G4Track.hh"

class OneHit : public G4VHit{
public:

    OneHit();
    virtual ~OneHit();

    // methods from base class

    // set methods
    void SetEDep(G4double E)           {fEDep = E;};
    void SetTrackLength(G4double L)     {fTrackLength = L;};
    void SetPhotonCounter (G4int p)     {fPhotonCounter = p;};

    // get methods
    G4double GetEDep()                  const { return fEDep;};
    G4double GetTrackLength()           const { return fTrackLength;};
    G4int GetPhotonCounter()            const { return fPhotonCounter;};

private:
    G4double      fEDep;
    G4double      fTrackLength;
    G4int         fPhotonCounter;
};

typedef G4THitsCollection<OneHit> HitCollection;

#endif
```

## OneHit.cc

```
//Include Custom Classes
#include "OneHit.hh"

//Include Native G4 Classes
#include "G4UnitsTable.hh"
#include "G4VVisManager.hh"

#include <iomanip>

OneHit::OneHit():fEDep(0.), fTrackLength(0.), fPhotonCounter(0) {}

OneHit::~~OneHit() {}
```



# SensitiveDetector Class (header)

```
#ifndef SensitiveDetector_h
#define SensitiveDetector_h 1
```

```
//Include Custom Classes
#include "DetectorConstruction.hh"
#include "OneHit.hh"
#include "PhotonHit.hh"
```

```
//Include Native G4 Classes
#include "G4VSensitiveDetector.hh"
#include "G4TouchableHistory.hh"
#include "G4OpBoundaryProcess.hh"
#include <vector>
```

```
class G4Step;
class G4HCofThisEvent;
```

```
class SensitiveDetector : public G4VSensitiveDetector
{
public:
```

```
//Constructor
SensitiveDetector(const G4String &SDname, const G4String &HitCollectionName);
//Destructor
virtual ~SensitiveDetector();

void Initialize(G4HCofThisEvent *HCE);
G4bool ProcessHits(G4Step *step, G4TouchableHistory *ROhist);
void EndOfEvent(G4HCofThisEvent *HCE);
```

```
// Add methods
// // Total deposit Energy
void AddEdep(G4double edep) {fE += edep;};
void DeleteTotalE() { fE = 0.;};
G4double GetTotalE() const {return fE;};

// // Total Track Length
void AddTrackLength(G4double l) {fL += l;};
void DeleteTotalTrackLength() { fL = 0.;};
G4double GetTotalTrackLength() const {return fL;};
```

**Mandatory methods**

**Your function definitions to build the hit**

```
// // Photon Counter
void SetCounterStatus(G4int p) {fP +=p;};
void ResetCounterStatus() {fP = 0;};
G4int GetCounterStatus() const {return fP;};
```

```
// // // // //
G4bool IsAnOpticalPhoton(G4Step* aStep);
void CleanSDMemory();
void PrintSDMemoryStatus();
```

```
private:
HitCollection *fHitCollection;
G4double fE;
G4double fL;
G4int fP;
```

```
};
#endif
```

**Your private members**

Remember to add ALL your hit collection objects as member of the sensitive detector class and to include them



# SensitiveDetector Class (source)

```
//Include Custom Classes
#include "SensitiveDetector.hh"
#include "OneHit.hh"
#include "PhysicsList.hh"

//Include Native G4 Classes
#include "G4ThreeVector.hh"
#include "G4SDManager.hh"
#include "G4ios.hh"
#include "G4TouchableHistoryHandle.hh"
#include "G4TouchableHistory.hh"
#include "Analysis.hh"
#include "G4RunManager.hh"
#include "G4UnitsTable.hh"
#include "G4Step.hh"
#include "G4HCoThisEvent.hh"
#include "G4Tubs.hh"
#include "G4OpticalPhoton.hh"
#include "G4OpBoundaryProcess.hh"
#include "G4GeometryTolerance.hh"
#include <math.h>

using namespace std;

static const G4double GeometricalTolerance = G4GeometryTolerance::GetInstance()->GetSurfaceTolerance();
```

```
SensitiveDetector::SensitiveDetector(const G4String &SDname,const G4String &HitCollectionName)
: G4VSensitiveDetector(SDname),
  fHitCollection(NULL),
  fE(0.),
  fL(0.),
  fP(0.),
{
  G4cout<<"Creating SD with name: "<<SDname<<G4endl;
  collectionName.insert(HitCollectionName);
}
```

**Class constructor:**  
Remember to initialize all the members (also all the hit collections)

```
SensitiveDetector::~SensitiveDetector() {}
```

**Class destructor**

```
void SensitiveDetector::Initialize(G4HCoThisEvent *HCE)
{
  fHitCollection = new HitCollection(GetName(),collectionName[0]);
  static G4int HCID = G4SDManager::GetSDMpointer()->GetCollectionID(collectionName[0]); //<<-- this is to get an ID for the collectionName[0]
  G4cout<<"*** "<<fHitCollection->GetName()<<" initialized [ID = "<<HCID<<"]"<<G4endl;
  HCE->AddHitsCollection(HCID, fHitCollection);
}
```

Add to your sensitive Detector the Hit collection and give it an univoque ID

# SensitiveDetector Class (source)

```
G4bool SensitiveDetector::ProcessHits(G4Step *aStep, G4TouchableHistory *)
{
    G4double eDep = aStep->GetTotalEnergyDeposit();
    G4double deltaL = aStep->GetStepLength();
    G4int counter = 0;

    if(SensitiveDetector::IsAnOpticalPhoton(aStep))
        counter ++;

    //SensitiveDetector::SetCounterStatus(counter);
    SensitiveDetector::AddEdep(eDep);
    G4String myParticle = "e-";
    G4String thisParticle = aStep->GetTrack()->GetParticleDefinition()->GetParticleName();
    G4String thisVolume = aStep->GetTrack()->GetVolume()->GetName();
    if(thisParticle==myParticle){
        //G4cout<<"[DEBUG]: I Found "<<thisParticle<<G4endl;
        //G4cout<<"[DEBUG]: I Found "<<thisParticle<<" in the Volume: "<<thisVolume<<G4endl;
        SensitiveDetector::AddTrackLength(deltaL);
    }
    G4int pDetected = 0;
    if(thisParticle=="opticalphoton"){
        G4String procName = aStep->GetPostStepPoint()->GetProcessDefinedStep()->GetProcessName();
        G4bool checkAbsorption = procName.contains("Absorption");
        if(checkAbsorption==true and thisVolume=="SiPM")
            pDetected +=1;
    }

    SensitiveDetector::SetCounterStatus(pDetected);

    return true;
}
```

This is the main part in which you create your hit starting from the information that you can retrieve by

- G4Step
- G4Track

## SensitiveDetector Class (source)

## Your «AUXILIARY» function definitions

```
G4bool SensitiveDetector::IsAnOpticalPhoton(G4Step* aStep){
    G4bool flag = false;
    G4Track *aTrack = aStep->GetTrack();
    const G4ParticleDefinition* aDef = aTrack->GetParticleDefi
    G4String aName = aDef->GetParticleName();
    if(aName=="opticalphoton"){
        flag=true;
    }
    return flag;
}
```

*Check if the particle is an optical photon*

*Check if the particle is an Optical photon*

```
void SensitiveDetector::CleanSDMemory(){
    SensitiveDetector::DeleteTotalLE();
    SensitiveDetector::DeleteTotalTrackLength();
    SensitiveDetector::ResetCounterStatus();
}
```

### Reset the SD Memory status

[illegible]

### Get the SD Memory status

# SensitiveDetector Class (source)

```
void SensitiveDetector::EndOfEvent(G4HCofThisEvent*)
{
    //Fill the hits
    OneHit *aHit = new OneHit();
    G4double TotE = SensitiveDetector::GetTotalE();
    G4double TotL = SensitiveDetector::GetTotalTrackLength();
    G4int TotP = SensitiveDetector::GetCounterStatus();

    aHit->SetEDep(TotE);
    aHit->SetTrackLength(TotL);
    aHit->SetPhotonCounter(TotP);

    fHitCollection->insert(aHit);

    SensitiveDetector::PrintSDMemoryStatus();
    G4cout<<"!!!EndOfEvent!!!"<<G4endl;
    SensitiveDetector::CleanSDMemory();
}
```

## EndOfEvent:

- Retrieve the current SD memory status
- Insert your score in the hit
- Print the status on screen
- Print a message for the end of event
- Clear the memory